



**Notes:**

1. Refer to City of Sanford drawing SD-R-003 for asphalt patch details if necessary.
2. Use high bypass models only.
3. Meters furnished by City.
4. Place washed stone under and around pipe to protect corporation stop.
5. Mueller or Ford brass valves, yoke fittings, and stops shall be provided.



## Tap & Meter w/ Custom Setter

City of Sanford Engineering Dept - P.O. Box 3729 - Sanford, NC 27331

Dwg. No. SD-W-002

Date: 06/30/2020

Scale: Not To Scale

Drawn By: Staff